lssue 802

September



Approved for Public Release Distribution is

Unlimite





PREVENTIVE MAINTENANCE MONTHL

3

ISSUE 802 SEPTEMBER 2019

COMBAT VEHICLES

M1-Series Tank Parking Brake PMCS	3
M2/M3-Series Bradley M242 14-Pin Connector	4-5
M88A2 Fire Prevention Tips	6-7
M113A3 FOV Overheating Prevention	8-10

TACTICAL VEHICLES 11

0-0-0	
M1075/A1 PLS Transfer, Transmission Shifting	11-13
FMTV Wheel Bearings Repack Interval	14-15
M1151A1 HMMWV Gunner's Sling NSN	15
MRAP Luminous Tape Placement	16

AVIATION 17

MEDEVAC External Rescue Hoist Washer Chang	
MEDEVAC Internal Rescue Hoist Lanyard Check	18-19
MEDEVAC Hoist Briefings	19
AGSE Composite Repair Kits	20
UH-60M Searchlight Replacement	21
UH-60A/L/M, H-60 Series EBAPS Kit PN Change	22
Shadow UAV Maintenance Tips	23-26
Crushing the ETM/IETM	
MSD Conundrum	27-34
MISSILES	35

HELLFIRE Missile System PM Tips 35-37 Connie's Post Scripts

SMALL ARMS

38

45

48

	12
JSGPM Carrier Security	42
Stuck Parts, No Acetylene Torch Allowed	42
CCMCK Caution	41
M249 Machine Gun Feed Box Support Kit Update	40
M249 Machine Gun, No Barrel Collar Movement	39
M68 Reflex Sight PM Tips	38-39

IOULS 43 43-44

TMDE Calibration App



M9 ACE Hatch Hinge Lubing 45 HYEX Swing Bearing Ring Gear Lube 46 120M Road Grader Cab Safety 47

COMMUNICATIONS

- AN/VRC-104(V)5 Radio Installation Kit 48 5-kW TOG Muffler Gasket NSN 49 ICIDS-V TM Released 49

SOLDIER SUPPORT 50

Gas Cylinder Turn-in Help	50-51
Fuel and Water Can Facts	52-53
Medical Repair Parts through GCSS-Army	53-54

LOGISTICS MANAGEMENT 55

LLRC Inspections	55-56
UIC Transfer Instructions	57-58
GCSS-Army Warehouse Activity Monitor	58-59

60-61

TB 43-PS-802, The Preventive Maintenance Monthly, is an official publication of the Department of the Army, providing information for al Soldiers assigned to combat and combat support units and all Soldiers with unit maintenance and supply duties. All information published has been reviewed and approved by the agency responsible for the equipment, publication or policy discussed. Application of the information is optional with the user. Masculine pronouns may refer to both genders. The use of product or company names does not constitute endorsement of those products, services or companies by the U.S. Army. The use of non-DoD hyperlinks, along with their content, does not constitute endorsement by DoD or DA. Neither DoD nor DA exercises any editorial control over, and cannot vouch for, content on non-DoD websites.

> PS, The Preventive Maintenance Monthly (ISSN 0475-2953) is published monthly by the Department of the Army, Redstone Arsenal, AL 35898.

You are invited to send PS your ideas for improving maintenance procedures, questions on maintenance and supply problems and guestions or comments on material published in PS.

Just write to:

MSG Half-Mast PS, the Preventive Maintenance Monthly USAMC ARMY SUSTAINMENT COMMAND BLDG 3307 Redstone Arsenal, AL 35898

Or email:

usarmy.redstone.asc.mbx.psmag@mail.mil

Internet address: https://www.aschq.army.mil/home/psmag.aspx By Order of the Secretary of the Army:

JAMES C. MCCONVILLE General, United States A Chief of Staff

Official

Kithlan S. Miller KATHLEEN S. MILLER rative Assistan

to the Secretary of the Army 1916956

DISTRIBUTION: tronic media only/EMO) ed in el

Back to Basics Readiness



Lt's time to reflect on past accomplishments and failures. The goal is to implement new plans that will maintain past successes and improve weak areas. For logisticians, this means reflecting on lessons learned from past missions and projects to improve processes needed to maintain readiness and predict future requirements.

I'd like to reflect on the days of old when TA-50 layouts, room inspections, field recovery, equipment maintenance, inventories and weapons cleaning were commonplace in a Soldier's daily activities.

As a young Soldier, I struggled to understand why we had to do these things over and over again. When returning from a long field exercise, visions of a hot shower and the bed quickly overshadowed the diligence needed to complete recovery activities.

Later, I found out quickly, and sometimes painfully, that those basic logistical checks and balances served as the foundation of readiness.

Something as simple as not recovering the heater for the tent and ordering required maintenance parts created a "cold" hard lesson during the next field problem.

During an FTX, a leader who overlooked the TA-50 inventory found that a Soldier had just a blanket because his sleeping bag fell off the truck during the previous field exercise.





A deployed Soldier had a flat tire in the middle of the desert and realized that the BII was short the jack and wrench.

These are but two examples of **readiness challenges** that could have been **prevented** by following the basic requirements outlined in command supply and maintenance doctrine and policies. Supply and maintenance discipline programs serve as the bedrock of combat readiness.

The Army provides all units with equipment and materiel needed to accomplish missions. Our mission as logisticians and sustainers is to ensure that we keep these resources in a mission-ready state. Let's get back to the basics of readiness.

Through command emphasis and activities such as recovery, inventory, maintenance and requisitioning replacement items, we lay a solid foundation for readiness. As logisticians and leaders, we play a critical role in ensuring the world's greatest fighting force is trained, manned, and equipped.

As the Chief of Staff of the Army has pointed out, "Readiness is our number one, there is no other number one." With this in mind, let's get back to the basics of supply and maintenance discipline to improve readiness and ensure the Army is ready to fight and win the Nation's wars.

CW5 Cheryl M. Bartly DCS, G-4

This article originally appeared in the January 2019 issue of *Property Accountability Newsletter.*



M1-Series Tanks...

Parking Brake Part of PMCS

HEY! WHERE

YA THINK YOU'RE GOING?

Dear Editor,


One PMCS check that tends to get overlooked by M1-series tank crewmen is making sure the parking brake works. It's a simple check but an important one because you don't want a tank moving when it shouldn't!

NOT MY

FAULT!

Before doing this check, make sure to warm up the engine for at least two minutes. If you don't, the engine and transmission could be damaged.

Just like the -10 TM says, once the engine is warmed up, move the shift control to D and run the engine just above idle speed. That's 1,000 to 1,100 rpms. The tank shouldn't move. If it does, tell your mechanic right away.



Also, if your tank's rpm gauge isn't working, you can still do the check by moving the shift control to R with the engine at normal (850 to 950 rpms).

> SSG Mark Diaz Ft Hood, TX

Editor's note: Good info to know, Staff Sergeant Diaz!

YOU NEVER DID PM ON MY PARKING BRANDWARD

YOU NEVER

M2/M3-Series Bradley...

FOOD FOR M242 FEEDER THOUGHT




Just one moment of carelessness or rough handling can knock out that connector. And it happens time and time again. Current figures show M242 motor drive replacements for broken connectors average 60 per month at an annual cost of \$4 million! Just remembering a few tips can wipe out that cost.




WHEN YOU INSTALL THE FEEDER, MAKE SURE IT'S **PROPERLY ALIGNED** ON THE RECEIVER **BEFORE** YOU PUSH UP THE LOWER STRAIGHT DRIVE SHAFT.

If feeder is correctly aligned on receiver, drive shaft should lock in place easily



If the shaft doesn't want to go up, the feeder isn't aligned right. Reposition the feeder and try again. If the shaft won't go up even after you reposition the feeder, *STOP*.

Get your mechanic to check out the problem.



Part of the problem is that the M242's TM 9-1005-200-23&P gives a *different* feeder installation procedure than the Bradley's -10 TMs. The -23&P's is the correct procedure. But, unfortunately, Bradley crews usually don't see the M242 TM.

The key difference in the TMs is that the M242 TM correctly says to lock the drive shaft in place before pushing down the feeder handle to lock it in place. That ensures the feeder is correctly aligned so the 14-pin connector *doesn't* get damaged.

The Bradley TMs, on the other hand, have gunners lowering the feeder handle before locking the drive shaft in place. This negates the value of using the drive shaft as an alignment check.

The *easiest* solution is to print out the correct procedure from the M242 TM and give a copy to every Bradley crew in the unit.

First, go to https://idmng.armyerp.army.mil/



TM 9-1005-200-23&P. The feeder installation procedure begins in WP 0026 00-9.

It's equally important to remember when the feeder is removed, the feeder handle *must* be put in the *down* position before placing the feeder on the floor.


The feeder handle serves as a stand for the feeder, much like a kickstand on a bike, and protects the 14-pin connector.

But crews need to remember the feeder handle must be put back in the up position *before* trying to align the feeder with the receiver.

It *can't* be done if the handle is down.

click on the ETM app to download


Before setting feeder on around, put feeder handle in down position to protect 14-pin connector



Soldiers come and go in Bradley units. That's why the correct procedures for installing and removing the feeder need to be *constantly taught* and why copies of the M242 TM procedure are a must. It takes so little time to go over the procedures, but will save so much time and money in 14-pin connector repairs.

M88A2 Recovery Vehicles...

PREVENT FIRES WITH PREVENTIVE MAINTENANCE






Oil and fuel pooling in the bottom of the crew, hull and engine compartments is a big concern because it can make fires much *more difficult* to extinguish.

Always clear fluid and debris from the vehicle before operations.

Here's how:

Crew Compartment


Check for water, fluids and debris that can collect on crew compartment floor plates. Remove any debris and then pull the drain lever next to the driver's seat in the crew compartment. Allow any fluid to drain. If you see oil or fuel in the drained fluid, check for fuel leaks and make sure they're repaired before operating the vehicle.



Hull Compartment


Lift the floor access panel behind the driver's seat and check for fluid in the hull compartment. If you see fluid, clear away any debris, position a drip pan, and then open the front drain valve.

Do not operate the vehicle without the drain valve or access plates installed. That can allow debris to get inside the engine compartment. It can also affect the engine cooling system and cause the engine to overheat.



Engine Compartment

Remove the front engine deck grille doors to check for fluid in the engine compartment. If fluid is present, clear any debris, position a drip pan, and remove the rear drain plug.




Then open the driver's and mechanic's engine exhaust grille doors, as well as the transmission access doors. Remove any fluid or debris through the engine compartment bottom access panels. Also, be sure to check for fuel or oil on the exhaust grilles.





Coolant Levels


If the coolant is low, the engine overheats and is ruined. So remove the radiator cap and check the coolant level daily before operations. If the coolant is hot, check that the coolant reaches HOT FILL LEVEL in the filler neck. If coolant is cold, check that coolant reaches COLD FILL LEVEL in the filler neck. Add coolant as needed. If water was added, ask your mechanic to check the antifreeze protection level. Careful, hot coolant can burn you! Only use your hand to remove the cap if it's cool to the touch.



Engine Warmup

Your engine will last longer if you always warm it up before you head out. You need to give the oil time to circulate before moving your carrier. Check that the ENGINE OIL LOW PRESS warning light goes off within 10 seconds after engine start. Check that the BATT GEN indicator points to the green zone.

Run the engine at 1,000-1,200 rpm for three to five minutes. Then reduce the engine to idle speed (600-700 rpm).



Engine Shutdown

Stopping the engine without a cooling down period can damage the engine. Don't stop the engine before the coolant temperature drops to 185°F or lower. Run the engine at 1,000-1,200 rpm for three to five minutes. Then return the engine to normal idle at 600-700 rpm. Pull the fuel cutoff control all the way out to stop the engine and set the MASTER SWITCH to OFF.

PS 802




Air Cleaner

Your engine will lose power and overheat if the air cleaner element is choked with dirt. Check the air cleaner indicator often. If at any time only red shows in the window, tell your mechanic.

Belts

Check generator, coolant pump, and coolant fan drive belts for looseness, wear and damage. Replace any drive belt that's missing, broken, has cracks on the belt fiber, has more than one crack ($^{1}/_{8}$ inch in depth or 50 percent of belt thickness) or has frays more than two inches long.

Check the idler adjuster for proper adjustment between the operating range marks. If the idler is not in operating range and the coolant fan drive belt has more than $\frac{1}{2}$ inch deflection between pulleys, tell your mechanic.



Radiator Fins

The radiator can't do a good job of conducting heat if its fins are clogged with dirt, oil, leaves, grass or twigs. Anything that restricts airflow through the radiator keeps the coolant hot and overheats the engine. Your mechanic can clean the fins with low-pressure water.

Keep packs, water cans, tents, camouflage screening, poles and other equipment off the air intake and air exhaust grilles.

Make sure both are clean and free of dirt, twigs, leaves and other debris. If you use protective covers over the grilles, make sure they're rolled up and strapped in place before operating your vehicle.











Slippery Conditions

Driving the M1075 PLS can be *challenging* in wet, slippery, muddy or snowy conditions where operators must frequently shift the transfer from high to low and vice-versa to keep the truck moving.




In some cases, operators must switch the transmission from drive to neutral *a few times* while shifting the transfer in order to achieve the desired range. Transmission and transfer case operation for the M1075 PLS is detailed in WP 0034, and specific transmission ranges are listed in WP 0010, Table 1 of TM 9-2320-364-10-1 (Sept 16).





Normal Conditions

If operators fail to shift out of low into high range and drive the truck faster while still locked in low range, the drivetrain and transfer will definitely be damaged.



Normal Conditions, continued

It's also a **huge error** to engage the transfer case:

- while the truck is moving.
- when the transmission is in gear.
- when the wheels are slipping.
- when turning a corner.


Any one of these scenarios will seriously damage the transmission because it engages the transfer case while the wheels are still spinning.



Signs of Damage

Clear signs the truck has been operated at high speed while locked in low range or shifted while the transmission is in gear include:

- grinding noises.
 locked gears.
 metal shavings
 - or chunks in the transfer case, usually discovered when the case is drained or flushed.




TO KEEP OPERATORS PROPERLY TRAINED, UNITS SHOULD MAKE SURE THEIR DRIVER SUSTAINMENT TRAINING PROGRAM FOLLOWS THE REQUIREMENTS OF AR 600-55, THE ARMY DRIVER AND OPERATOR STANDARDIZATION PROGRAM (MAY 17), AVAILABLE AT: https://armypubs. armu.mil/ ProductMaps/ PubForm/AR.aspx



The Fix







REPACK!

IT'S NO WONDER YOU'RE CONFUSED. THE TMS ARE UNDER REVISION TO CLARIFY THIS ISSUE.

Dear Half-Mast,

I work at a TACOM FMX where we maintain a fleet of FMTV-series vehicles, including LMTVs and MTVs.

The TM for these vehicles says to check the wheel bearings every 12,000 miles or once a year, and to repack the bearings every 12,000 miles or when an inspection reveals an oil leak or when the wheel assembly is taken apart for other maintenance.

Our practice is to remove the wheel hubs and bearings on these FMTVs every year, regardless of the mileage. We clean, inspect and repack the wheel bearings, even on vehicles that have not met the 12,000 mile mark.

Are we doing the right thing by removing these bearings every year, or are we wasting man-hours, repair parts and training time?

Mr. W.H.J.

Dear Sir,


This is a tricky question because the TM for the -A1 models says to repack every 12,000 miles. But the TM for the -A1P2 models says to repack every 12,000 miles OR annually, whichever comes first.

TACOM tells me they're in the process of revising the TMs to be consistent between both models. The -A1P2 model TM will be revised to say: "Repack the bearings every 12,000 miles or when an inspection reveals an oil leak or when the wheel assembly is taken apart for other maintenance."

Half-Mast-



M1151A1 HMMWV...




Dear Half-Mast,

Is there a gunner's sling for the M1151A1 HMMWV? I looked all through TM 9-2320-387-10 and couldn't find one.

PFC Z.G.






PS 802


BRING IN THE GLOW!

The door handles and escape hatches inside MRAP vehicles are hard to see, especially in the dark. That's because there's only a slight color contrast between the handles and surrounding area.

Seconds can count on the battlefield, so add a little glow to the situation by adding a strip of *luminous tape*, NSN 9390-01-573-0835, in all the right places.

Inside the MRAP, place the tape on the escape hatches and doors like so:






By the way, this tape works on composite and non-metallic surfaces. Just wipe off the area first with some alcohol wipes. Then dry it with a clean rag before applying the tape.

MEDEVAC...

TM Change Coming for External Rescue Hoist Washer

Mechanics, things in aviation can change on a dime. The MEDEVAC Breeze-Eastern commercial manual, TD-01-006, (Rev D, w/changes, Jun 18), included a technical publications deficiency report (TPDR) that replaced one of the hoist hook washers, PN BL-11684-1, with NSN 3120-01-624-2150 (PN BL-11684-2).






Replacement washer is thinner



New hoists and hook assemblies already have the new washer installed. But the new NSN and part number *haven't* been added to the manufacturer's manual or the aircraft TMs.

The change is in the works. But until it happens, add the new NSN and part number to Item 15 in Fig 4-157 of TM 1-1520-237-23&P and Item 16 in Fig 14-2 of TM 1-1520-280-23&P.



M

drum from a safety clip ingested into the running hoist.


The reason this happened isn't clear. But the clip and lanyard, which were attached to the hoist and designed as a safety for the upper hoist connection, came loose during operation.







Several different lanyard styles are in current use. No matter which one you have, it's a good idea to check the lanyard for problems. Make sure the lanyard is long enough to allow installation of the clip on the upper hoist connection, but not so long that a free-hanging clip can get ingested into the running hoist.







Need a MEDEVAC Hoist Briefing?



Mechanics, if you have an upcoming safety standdown, PD MEDEVAC will come to your unit to brief users on hoist issues. They'll also provide info on upcoming changes to hoist maintenance-related operational procedures and TM updates.


What does PD MEDEVAC need?

- 1. An invite
- 2. A classroom
- A projector
- The unit's undivided attention for about three hours

Take advantage and get better informed about MEDEVAC hoists. To request a visit to your unit, email Tracy Hicks at: tracy.d.hicks.civ@ mail.mil AGSE...

Composite Repair Kits Have the *Right* Tools!





HOW AM I GOING TO

GET THE COMPOSITE

REPAIRS I NEED?



The **K3000 composite repair kit**, NSN 4920-01-628-2469, is a portable kit with specialized tools used to make composite repairs while away from a fixed facility.

WE'RE IN THE

MIDDLE OF


NOWHERE!


The PD AGSE folks have integrated the K3000 composite repair kit into two separate aircraft tool sets. In each Aviation Maintenance Company (formerly AVUM), the K3000 is in the Aviation Unit Maintenance Tool Set: No. 2 Airmobile-Enhanced, NSN 4920-01-551-7472.


The composite repair kit is also in each Aviation Support Company's (formerly AVIM) Tool Crib Shop Set, NSN 4920-01-600-7362.

The Aviation Support Companies also have the **Composite Shop Set**, NSN 4920-01-600-7365, which provides tools and some materials to make higher level composite repairs to aircraft.

UH-60M... REPLACEMENT SEARCHLIGHT **NOW AVAILABLE!**







Dear Editor,


We help keep the Shadows flying at Ft Stewart. So we're providing a few tips to keep your Shadows in the air:

• Use the TM. There are a lot of checks for the Shadow and its launcher. Missing just one could lead to a crash. So use the TM. It's the only way to ensure you don't miss anything.

Remember, a technical inspector needs to verify and document everything you do, including repairs. That ensures your Shadow has a safe flight and you won't be blamed if something goes wrong.




• Be careful out there. Just a bump can snap off the pitot tube or the communications relay system (CRS) antenna. Tie warning tags to both to help Soldiers remember to give them a wide berth.




Before moving a Shadow, put the propeller in the horizontal position. That prevents the propeller from being damaged hitting the ground.


- Remember the tactical automatic landing system (TALS) storage pins. If you forget to remove the pins, they can cause damage when the TALS is turned on.
- Check the oil pressure indicator. The indicator light must go off before the Shadow is launched. If the light doesn't go off, the oil pressure may be low. Check it out.



Don't forget to remove TALS storage pin


• Eyeball the oil line for air bubbles. If any of the bubbles are larger than 1/4 inch, do the oil pump bleeding procedure. That air bubble could prevent enough oil from getting to the engine.






- No tape for fuel filter. Don't use plumbers' tape on the fuel transfer pumps to keep the filter or fuel lines from leaking. Bits of the tape can break loose and clog the filter. Make sure there are no tape bits in the filter.
- Do the caliper brake pressure adjustment for arresting gear like it says in the TM. If you don't properly set the caliper brake pressure to a tolerance of 85±20 lb-ft, the Shadow could have a landing mishap.

Keep caliper brake pressure to 85 (±20) lb-ft



• Don't forget the launcher. Pay particular attention to the rails. Check for FOD. Something as small as a pebble could damage the Shadow and the launcher rail.


PS 802



25



Make sure you've set both brakes and chocked both wheels. Don't forget that the launcher's shovels must be emplaced in dirt. Concrete can snap off the shovels' teeth.



26

PS 802


THANKS TO THE SERGEANTS AT FT STEWART, I NOT ONLY


MAKE IT INTO THE AIR ...


SEP 10

...BUT I MAKE IT BACK DOWN, TOO!


Crushing the ETM/IETM MSD Conundrum








PS 802





PS 802



to the software using just your username and password.








PS 802








HELLFIRE MISSILES CAN PO SERIOUS DAMAGE IF BOTH THE LAUNCHER AND MISSILES ARE IN FIGHTING SHAPE.

BUT IF EITHER ONE IS SUFFERING FROM NEGLECT, YOUR HELLFIRE FIRING JUST WENT TO ZERO. KEEP YOUR HELLFIRES FIRED UP FOR FIRING WITH THIS PM!

Launcher

Use shotgun connector covers. If the covers are left sticking up, dirt and sand plug up the connectors and kill the electrical connections to the missiles. Make sure they're working properly and are aligned right. If the covers aren't completely sealing the connectors, tell your repairman. He can adjust them.



ARMY





Launcher. continued


Clean shotgun connectors. The connectors still need to be checked for dirt before a mission. Use a flashlight to look for dirt in all four sets of connectors. If you find any, use a clean wiping rag dampened with water and detergent, NSN 7930-00-282-9699, to clean out the dirt. Remove dirt and debris from the exterior surfaces. Don't clean inside the connector with water. Use low-pressure air to blow out any dirt in the connectors.




Check for burrs and corrosion. Burrs and corrosion on the inside of the launcher rails make it difficult to load missiles. Look for burrs and corrosion whenever the launcher is removed or installed. Eyeball each rail inner surface for roughness or notching. Damage to the inside of the rails can't exceed a maximum of .007 inches.

Clean off corrosion following the procedure in TM 1-1500-344-23. Never file or sand the launcher. The plating residue can be dangerous if it gets in your lungs. Filing and sanding also cause dirt and sand to collect on the rails, which causes more loading problems.

Don't lube the launcher. That just causes dirt and sand to collect on the rails, which causes evenmore problems.



Loading



the missile itself.

36



The correct way to load is to place the latch handle to UNLATCH. Slide the missile slowly down the rail until the forward shoe is engaged in the rail track and the missile contacts the stop blocks. Move the handle to LATCH while holding the missile in place.

Make sure the latching handle actually latches. The handles get beat up from feet and bumps and they quit working. When the missile is latched, the handle shouldn't move more than 10 degrees. If it moves more, the handle may be damaged. Tell your repairman.




Missiles

Protect 'em. HELLFIRE missiles need all the protection you can give them. Keep them in their storage containers as much as possible.

HEY! I'M NAKED OLIT HERE WITH NO PROTECTION! PROTECTION! PROTECTION!

If you have access to dome covers, use them.

Don't use the fins as handles. They break and that puts the missile out of action. Hold the body of the missile to guide it into place on the launcher.





M68 Reflex Sight...


SIGHT IN ON THESE SIGHT TIPS

GEEZ! WHAT'S WITH THE REFLECTION? ARE YOU TRYING TO TELL THE ENEMY WHERE TO SHOOT?

HEY, MAN, DON'T BLAME ME! YOU'RE THE ONE WHO TOOK OFF MY ANTI-REFLECTIVE CAP.

Here are a few ways to help your M68 reflex sight keep you on target:

• Easy does it with the windage and elevation adjustment caps. Some Soldiers crank the caps so hard that the whole cap breaks off. Often the only fix is to replace the whole sight. Once the cap doesn't want to turn more, stop turning.



• Don't use your shirt as a cleaning instrument. The M68 has delicate lenses that can be quickly scratched up by something as rough as your shirt. If you can't see through the lenses, the sight is no good. Your armorer should have lots of lens paper made specifically to clean delicate sights. Get a pack and store it in your pack. If your armorer needs more lens paper, he can order a **pack of 100** tissues with NSN 6640-00-240-5851.



 Make sure you're using TM 9-1240-413-13&P (May 13). It replaced TM 9-1420-413-12&P, which doesn't cover the newer M68 versions.

- Don't remove the anti-reflective cap. Soldiers often remove the cap because that makes it easier to use the backup iron sight (BUIS). But the cap serves two critical functions:
 - It prevents a reflection from signaling your position to the enemy. That could mean the difference between life and death on the battlefield.
 - It protects the M68's lens from scratches. If the lens gets too scratched, it's unusable.

Don't remove anti-reflective cap

Here are the NSNs for the M68 models: • CompM2,

- NSN 1240-01-411-1265 • CompM4,
- NSN 1240-01-540-3690
- CompM4S, NSN 1240-01-576-6134



Dear Half-Mast,

PMCS Step 2 in TM 9-1005-201-23&P says to check the M249 machine gun's barrel carrying handle collar for any movement. But it doesn't say if any movement is just a deficiency or if it makes the barrel non-mission capable (NMC). Can you clarify?

SPC K.H.


Any movement of barrel collar means NMC






Page 19 of PS 793 (Dec 18) talked about the importance of making sure your M249 machine guns have the feed box support kit installed.


Now you no longer need to contact TACOM if your M249s need the kit. The kit can be ordered with NSN 1005-01-560-1026 and installed by a 91F small arms repairman.



For installation instructions, see PS 793 at: https://www.logsa.army.mil/web2/archive/PS2018/793/793-19.pdf



PS 802



See https://www.logsa.army.mil/web2/archive/PS2018/784/784-38-39.pdf for instructions on how to check for obstructions in the barrel.

PART STUCK? NEVER REACH FOR ACETYLENE TORCH!

Dear Editor,

In my work as a LAR, I've seen several instances of repairmen using an acetylene torch to loosen stuck parts. Specifically, they've used a torch on stuck mortar breech caps, jammed M2 machine gun barrels and various artillery systems components.

This results in major damage to the equipment. It melts the metal and sends equipment to the junkyard.


Acetylene torches should **never** be used at field support to loosen any stuck part.

Repairmen who can't get a stuck part unstuck should send it to the next level of maintenance.

But never reach for an acetylene torch.

Andrew Guilliams Ft Sill, OK An acetylene torch can do tremendous damage!

Editor's note: This is clearly an instance where the easy way is the **wrong way**. To say the least, no repairmen should do anything that's not called out in the TM, especially if it involves torches.



Don't Let JSGPM Carrier Get Carried Away

The joint services general purpose mask (JSGPM) comes with two carriers: the chemical-biological mask carrier, NSN 8465-01-529-0599, and the individual carrier, NSN 8465-01-529-1397.


Both carriers rarely wear out. But units are ordering a surprising number of replacements. They aren't budget busters—the mask carrier costs \$52 and the individual carrier \$36—but the more units have to order, the faster the dollars add up.

One cause may be the carrier gets misplaced when it's not used and then is never seen again.

One way to stop carriers from disappearing is by keeping the carrier safely stored in a locker or trunk when not in use. Keep the locker or trunk in the CBRN room. Make sure each carrier is tagged with its mask's serial number so it's easy to match the carrier with its mask.





TMDE... KEEP CURRENT WITH CALIBRATION



Dear Editor,


At the Ft Stewart command maintenance evaluation and training team (COMET), we run across tools whose calibration deadline has passed. That means these tools can't be trusted to give an accurate reading. An inaccurate reading can lead to disaster in some cases.






PS 802


SEP 19



Operators, keep this PM tip in mind `cause it's a real noggin' saver! Without lube, condensation gets into the hatch hinge assembly's internal spring, creating rust. The spring weakens until it finally breaks. Then the hatch cover can fall on your head!



PS 802




Put a gag on the HYEX's chatter by removing the swing bearing's access cover to check the ring gear. Look for grease with a lot of grit buildup. If you find a heavy coating with a lot of crud, wipe it all off with a clean rag. Add new grease until it reaches ¹/₂- to 1-inch deep from the bottom of the ring gear. Too much grease can *damage* the swing gearbox seal. Remove any grease that's over the top

of the swing drive pinion.


Add grease ¹/2 to 1 inch deep

You'll find this info on Page 15-2 of TM 5-3805-280-10 (Feb 00).




Operators, keep these safety reminders front and center before you hop into your 120M road grader's cab for the day's run:

- Use three points of contact (two hands and one foot, or one hand and two feet) at all times when getting in or out of the cab.
- Make sure you face the vehicle when using the cab's ladder. Climbing while facing away from the vehicle is an accident waiting to happen!
- Keep the ladder's steps clean. Mud and dirt make the ladder slippery. Another accident waiting to happen!
- Never try to enter or exit a moving vehicle.
- Don't carry tools, supplies or other items when entering the cab. Instead, have someone hand them up to you after you're seated. The same holds true for exiting the cab.



• Controls aren't handholds! Don't touch them until you're ready to operate the grader.





Dear Half-Mast,

I've been trying to install the **AN/VRC-104(V)5 system**, NSN 5820-01-575-9257, in our HMMWVs. But I've found no information on how to do it. I've only got the antenna coupler and whip antenna user manuals from Harris. And they **aren't** useful for installing the system in vehicles.

Can you point me to any TMs or TBs specifically written for this installation? System component block diagrams and parts lists would be really helpful.

SGT D.M.

Dear Sergeant,


I asked my friend at the CCDC C5ISR Center to help out with this one. He says the radio installation kit you need is Harris #11080-4100-03, NSN 5895-01-551-6478. Cost runs about \$2,400.

As for the radio installation instructions, you'll need Harris installation training manual 10515-0388-4500. You can get it from Harris, but we've also uploaded it to our milSuite group at: https://www.milsuite.mil/book/groups/ps-magazine

TM 11-5820-1501-13&P (May 13) also has maintenance info for the AN/VRC-104(V)5. You'll need to log in with your CAC to view this TM since it's restricted, but you can do a pub number search with the ETM app. Go to:

https://idmng.armyerp.army.mil

Half-Mast



Dear Half-Mast, Our unit has an MEP-802A 5-kW tactical quiet generator (TQG), NSN 6115-01-274-7387, that needs an exhaust muffler gasket.

It's the only part in TM 9-6115-641-24P (Nov 12) that **doesn't** have an NSN. It's listed as Item 5 in Fig 14 with PN 88-20108.

I've tried FED LOG and MMO3 in GCSS-Army to find an NSN. Nothing comes up. *Help!*

SSG F.R.

Dear Sergeant,

That's why PS exists. PS stands for Post Scripts to TMs, which means we solve dilemmas like this one.

Use NSN 5330-01-390-5185 from TM-6115-642-24P (Oct 96). Note this change in the newer TQG TM, so you have it for the future.


The gasket is usually an authorized stockage list item, and there are plenty of them ready to issue.


Half-Mast-

Security Rules in ICIDS-V TM

TM 5-6350-307-10 (Jan 19) is the new operator manual for the integrated commercial intrusion detection system-V (ICIDS-V). The ICIDS-V monitors and controls personnel entry into Army areas and facilities.

TM distribution is restricted, so you'll need to log in with your CAC to: https://idmng.armyerp.army.mil/ Choose the "ETM/IETM" app and search for the TM.





If you have questions about cylinder returns, email: cylreturns@hudsontech.com



FUEL AND WATER CAN FACTS


Dear Half-Mast,

I see people using plastic cans for fuel, but I find no listing for them on wheeled vehicle hand receipts. I suspect they are, in fact, water cans.


Also, the authorized NSN for the **steel fuel can**, NSN 7240-00-222-3084, is not listed in TM 10-7200-200-13, (Feb 74), which is the only TM I'm aware of that covers fuel or water cans. So:

- 1. Which TM covers the current NSNs for plastic and steel fuel cans?
- 2. Which NSN gets a plastic fuel can?
- 3. How should plastic fuel cans be marked for diesel and gasoline use?

Mr. G.D.




HERE ARE THE ONLY	Description, Cage Code, and PN	NSN 7240-	Qty
AUTHORIZED	Can, gasoline (81349), MIL-53109	01-337-5269	3
ITEMBII:	Can, water (81349), MIL-C-43613 Type 1	00-089-3827	6



Medical Repair Parts in GCSS-Army



PS 802



USAMMA will *only* purchase repair parts connected to a maintenance work order in GCSS-Army.


Make sure your needed repair part is added to the component tab of that maintenance order.

Also, if you get stuck on another medical logistics question, don't forget to reference USAMMA's supply bulletins online at: https://www.usamma.amedd.army.mil/Pages/Supply-Bulletins.aspx






IMPORTANT:




INSPECT EACH CONTAINER AND KEEP AN EYE OUT FOR STRUCTURAL DEFECTS THAT INCLUPE...

- cracks, holes or ruptures in the container or its lid.
- deformities in the container that prevent it from being closed or sealed properly.
- dents that interfere with the gaskets and any tape that may be used to seal the item.
- damage to the mounting/ suspension system, including cracks, splits, tears, bond separation greater than ¹/₃₂ of an inch and/or missing special hardware.
- a shock mount that is 12 years or older than the date printed on the mount.
- a container suffering from corrosion.





Look at the LLRC's name plates to make sure that they *aren't* missing or unreadable. It's important to inspect the LLRC's skids, too. Skids should be wood packaging material (WPM) compliant. Defects reduce the skid's load bearing ability and without being compliant, they could get damaged during shipment.



Pay attention to the item type storage code and make sure that items that should be stored inside *are* stored inside.

And last, but not least, check the record receptacle, desiccate holder, lifting rings, stacking guides, relief valves and view ports for any signs of **corrosion or damage**.


Oh, and make sure there aren't any markings that are **missing**, **incorrect** or **unreadable**.

You can read more about LLRCs and get more packaging tips by downloading PSCC's *Packaging: The Basics* (Jan 18) from LOGSA's LIW website: https://liw.logsa.army.mil/res/documents/ Packaging_The_Basics_JAN_2018_sml.pdf


You'll need your CAC to access the document.




LogisticsAssistance...




- 1. Log into AESIP: https://www.aesip.army.mil/irj/portal
- Click on the <u>PBID tab</u>, and expand the PBID Request applications tab under <u>Detailed Navigation</u>. Select <u>PBID Maintain</u>. Input the PBID to which the UICs are currently aligned and click <u>Go</u>.
- 3. Type the gaining organization's PBID in the "Gaining PBID" field next to the UIC to be realigned.
- 4. Provide a comment below detailing which UIC is realigning to which PBID.
- Click <u>Validate</u> to make sure that everything is correct with the PBID and the gaining PBO will populate.
- 6. If the validation is successful, select <u>Review Maintenance Request</u> at the top of the page.
- Click <u>Submit</u> and you'll receive a request number.
- 8. The request number will populate in the gaining PBO's Universal Worklist to accept. Notify the gaining PBO.





- The losing and gaining PBOs should make sure the B290 relationship is correct in GCSS-Army and that the 803 structure is complete with realigned UICs.
- 2. Make sure the gaining PBO accepts realignment in their Universal Worklist. The transaction isn't complete until the realignment is accepted.











SEGMENT INFORMATION INCLUDES:

XX Unconfirmed Transfer Orders (TOs)

This represents the number of pick and put-away transfer orders that are unconfirmed.

XX Open posting change notices

This is the number of posting changes made to a material's batch (condition code). The notices clear if you've confirmed the TO in the Unconfirmed Transfer Orders segment.

XX Critical Deliveries

The number of customer outbound deliveries that don't have a picking TO created. Picking TOs are documents that prepare material to move out of the warehouse. A picking TO doesn't create if the delivery due list available stock check finds a new material with no picking strategy or a bin that is blocked for physical inventory.

XX Interim storage stock, without movement

This segment lists the number of items with discrepancies posted to "999 Differences". This includes items in the 916 shipping area deliveries IST. These items have already moved to the issue section with the TO confirmed, but the item hasn't been post goods issued. There are also the 092 and 922 segments which disappear if you clear up corresponding issues in the Unconfirmed Transfer Orders segment.





M870A1 Semi-trailer Hub & Drum Kit *Missing Parts*

Some of the M870A1 semi-trailer's hub and drum conversion kits, NSN 2530-01-643-7190, are missing three items:

- seal retainer, NSN 5330-01-255-0201; \$4/ea.
- tabbed washer, NSN 5310-01-049-9051; \$3.29/ea.
- grease cap, NSN 2530-01-520-5730, \$7.74/ea.

If your kit is missing these items, don't return it. Just order the missing parts, in quantities of two each per axle.

Unfortunately, units will have to pay for the missing parts until the current stock of kits is depleted. Then, the new kits will contain the missing components.

JGMTK Available

The Joint General Mechanics Tool Kit (JGMTK) is now available. Use the **current GMTK**, NSN 5180-01-548-7634, until stock is unserviceable. Then order the **new JGMTK** with NSN 5180-01-605-5146. The JGMTK meets Army and Marine Corps requirements with an upgraded case and additional tools. The new case is water-proof and meets increased impact resistance requirements.

M917A2 Dump Truck Tire and Wheel Assemblies

Can't find the complete tire and wheel assemblies for the M917A2? That's because the M917A2 doesn't currently have any assigned. But the correct info is provided in Figs 184 and 186 in TM 9-2320-302-24P (Feb 06, w/Ch 2, Aug 12) as follows:

M917A2 HET Tire Wheel Assembly	NSN	
Front tire	2610-01-436-3332	
Rear tire	2610-01-436-3334	
Front wheel	2530-01-518-7626	
Rear wheel	2530-01-518-6544	
Front pneumatic tire valve	2640-01-522-2413	
Rear pneumatic tire valve	2640-01-444-6175	

GOT AVIATION SAFETY QUESTIONS?

The Utility Helicopter Safety Office is ready to help units with any issues affecting aircraft safety. Email your safety inquiries or issues to: usarmy.redstone.peo-avn.mbx-uh-po-safety@mail.mil

LRT-110 Crane Oil Sending Unit NSN

Get a new engine oil pressure sending unit for your 7 $\frac{1}{2}$ -ton LRT-110 crane with NSN 6685-01-292-5205. It replaces NSN 6685-01-266-5848, which is shown as Item 47 in Fig 59 of TM 5-3810-305-24P (Sep 12). That NSN is a terminal item.

M9 ACE BATTERY SWITCHOUT

The M9 armored combat earthmover (ACE) is switching over from the old 6TMF-1 wet cell battery, NSN 6140-01-446-9498, to the 6TAGM (Hawker/Exide) battery, NSN 6140-01-485-1472. Make a note of this change until the new battery NSN is added to Item 7 of Fig 18 in TM 5-2350-262-24P (Jun 12).

Interrogator Sets TM Updated

TM 11-5895-1815-13&P (Feb 19) is the updated operator and field maintenance manual, including the repair parts and special tools list, for the AN/TPX-57(V)1, NSN 5895-01-530-4167, and AN/TPX-57(V)2, NSN 5895-01-590-4940, interrogator sets. It replaces TM 11-5895-1815-12&P (Jun 09).

TM distribution is restricted, so you'll need to log in with your CAC to:

https://idmng.armyerp.army.mil/

Choose the "ETM/IETM" app and search for the TM.

D6K Platform Wiring Harness NSN

Get a new platform wiring harness for your D6K dozer with NSN 6150-01-642-9874. It replaces NSN 6150-01-581-4090, which is shown as Item 15 in Fig 67 of TM 5-2410-240-24P (Jun 12). That NSN is no longer available.

M149A2 WATER BUFFALO HOSE ASSEMBLY

There's a new NSN for the M149A2 water buffalo trailer's hose assembly, shown as Item 7 in Fig 22 of TM 9-2330-267-13&P (Dec 15). Previous NSN 4720-01-440-9299 brought a 10-in hose assembly, but that's incorrect. The correct 13-in hose assembly comes with NSN 4720-00-851-8969.

ATLAS II Forklift Fuel Pump

A new high-pressure fuel pump for your ATLAS II forklift comes with NSN 2910-01-540-1530. It replaces NSN 2910-01-572-0995, which is shown as Item 7 in Fig 19 of TM 10-3930-677-23&P (IETM EM 0359, Aug 16).

PM Bridging Newsletter

PM Bridging's newsletter, *To Cross Is to Conquer*, has all the latest info on bridge erection boats, bridging system upgrades, testing, and revised TMs to cover operation, PMCS, maintenance procedures and parts changes. You'll find it at the UTAP website:

https://utap.army.mil

For logistical help with any bridging system, contact Marion Koreck at DSN 786-2239, (586) 282-2239 or email:

marion.j.koreck.civ@mail.mil

M969-Series Tanker Vapor Integrity Test Kit

The M969-series 5000-gallon fuel tankers need an annual vapor integrity test, as required by TM 9-2330-330-23P (Dec 15). But the TM doesn't list any equipment for the test in Table 2, "Tools and Test Equipment Requirements," which is where you'd expect to find it. Instead, you'll find the vapor integrity test set listed as Item 1 in Fig 84. Order it with NSN 2590-01-438-8806. Thanks to Jose Ruano of USAMSC-Korea for pointing out this fact!

Would You Stake Your Life ^{night now} on the Condition of Your Equipment?

DON'T SHIP US LIKE THIS!



Need shipping, packaging or preservation advice?

Call PSCC at: DSN 795-5319 or (570) 615-5319 Or email: usarmy.tyad.usamc.mbx.pt@mail.mil